



License Server Installation Guide-Linux CADfix 13.0

(DX, CAE, PPS, VIZ, STL)

ITI - International TechneGroup Limited

4 Carisbrooke Court, Anderson Road
Buckingway Business Park, Swavesey

Cambridge, CB24 4UQ England

Web: www.iti-global.com

Email eusupport@iti-global.com

Phone: (+44) (0) 1954 234 300

www.iti-global.com/CADfix

www.iti-global.com/cadfix-support

Copyright © ITI 2023

13/06/2023

ITI - International TechneGroup Limited

Public

Contents

1.1. Starting the license server	2
1.2. Recording license server information.....	3
1.3. Checking the license server status	4
1.4. Stopping the license server	4

1.1. Starting the license server

Before continuing, ensure you have a valid CADfix license file (cadfix.dat)

- 1) Download the CADfix License Server zipped package.
- 2) Create a CADfix license server folder.

```
mkdir CADfixLicense
```

- 3) Unzip the License Server package into the license server folder.
- 4) Copy your license file into the license server folder.
- 5) Check you have the correct files available to start the license service.

```
ls -l  
drwxr-xr-x 2 abc 90 1329 Jun 15 2020 3rd_party/itiohio  
drwxr-xr-x 2 abc 90 1144 Jun 15 2020 3rd_party/lmgrd  
drwxr-xr-x 2 abc 90 1112 Jun 15 2020 3rd_party/lmutil  
drwxr-xr-x 2 abc 90 4 Jun 15 2020 3rd_party/cadfix.dat
```

- 6) Run lmgrd to install a licensing daemon.

```
lmgrd -c cadfix.dat -l cadfix.log
```

cadfix.dat = the CADfix license file supplied by CADfix support.

cadfix.log = the license log file automatically generated by the license server. (This can be named differently if required).

This command will:

- Create the license daemons 'lmgrd' and 'itiohio'.
 - The daemons will reference the license file provided in this command. If the license file is in another location, then the license file should be qualified with a path.
 - The lmgrd daemon will use a default port number or use the one (optionally) defined in the license file.
 - The itiohio daemon will use a random port number each time it starts or use the port number (optionally) defined in the license file.
 - A log file will be generated using the name provided. A different name can be used if required. This log file will contain information about all the transitions carried out by the license daemons and is essential for support.
- 7) To interact further with the license daemon (validating/stopping/etc), you must identify the computer name and port number use for the lmgrd daemon. This information can be found in the log file generated when the license daemon was started. - See section [Recording License server information](#) for gathering this information from your cadfix.log file.

Public

1.2. Recording license server information

During the configuration of the CADfix License ([Starting the licences server](#)) the license log file was specified (e.g. "cadfix.log"). This log file contains the license server's configuration and license activities.

Open the log file with a text editor then find and record the following information:

FLEXnet version number:

Server network name or IP address:

License file name and path:

Lmgrd (license manager daemon) port number:


Itiohio (vendor daemon) port number:

Itiohio (vendor daemon) version number:

Method of linking to license server: Local license Short license Environment variable

The following is an extract from a cadfix.log file with this key information highlighted:

```
...
)
10:08:35 (lmgrd) Server's System Date and Time: Mon Jan 09 2023 10:08:35 GMT
10:08:35 (lmgrd) SLOG: Summary LOG statistics is enabled.
10:08:35 (lmgrd) FlexNet Licensing v11.16.4.0 build 252457 x64_lsb started on mainland (linux) (1/9/2023)
10:08:35 (lmgrd) Copyright (c) 1988-2019 Flexera. All Rights Reserved.
10:08:35 (lmgrd) World Wide Web: http://www.flexerasoftware.com
10:08:35 (lmgrd) License file(s): cadfix.dat
10:08:35 (lmgrd) lmgrd tcp-port 32768
10:08:35 (lmgrd) (@lmgrd-SLOG@) =====
...
...
10:08:35 (lmgrd) Starting vendor daemons ...
10:08:35 (lmgrd) Starting vendor daemon at port 27001
10:08:35 (lmgrd) Using vendor daemon port 27001 specified in license file
10:08:35 (lmgrd) Started itiohio (internet tcp_port 27001 pid 26804)
10:08:35 (itiohio) FlexNet Licensing version v11.16.4.0 build 252457 x64_lsb
10:08:35 (itiohio) SLOG: Summary LOG statistics is enabled.
...
...
```



1.3. Checking the license server status

- 1) Navigate to the CADfix license server folder.
- 2) Run the `lmutil lmstat` command. This will require your installation's specific values that match your license service. These values are shown in the license server's log file (`cadfix.log`)

```
lmutil lmstat -c [lmgrd port]@[server name]
```

Example:

```
lmutil lmstat -c 32768@mainland

lmutil - Copyright (c) 1989-2019 Flexera. All Rights Reserved.
Flexible License Manager status on Mon 1/9/2023 10:47

License server status: 32768@mainland
  License file(s) on dee: /home/abc/cadfix1200sp2/lic/cadfix.dat:

    mainland: license server UP (MASTER) v11.16.4

Vendor daemon status (on mainland):

  itiohio: UP v11.16.4
```

1.4. Stopping the license server

- 1) Navigate to the CADfix license server folder.
- 2) Run the `lmutil lmdown` command. This will require your installation's specific values that match your license service. These values are shown in the license server's log file (`cadfix.log`)

```
lmutil lmdown -c [lmgrd port]@[server name]
```

Example:

```
lmutil lmdown -c 32768@mainland

lmutil - Copyright (c) 1989-2019 Flexera. All Rights Reserved.

  Port@Host          Vendors
1) 32768@mainland   itiohio
```

You will be asked to confirm you want this license stopping:

```
Are you sure (y/n)? y
  1 FlexNet License Server shut down
```